

From  
Product  
Management

Eindhoven  
26.11.2008  
No. 26110801

## DVR4C List of recommended USB memory devices

Dear valued customer,

When using the DVR4C “USB Copy” function, Bosch Security Systems strongly recommends you to use the following brands/types of USB memory devices:

Brand	Type	Size	Test
Sony	USM128E	128MB	OK
Lexar	JDX256 Jumpdrive Elite	256MB	OK
Lexar	JDSP128 Jumpdrive	128MB	OK
Bosch (Databar)	-	128MB	OK
Apacer	HC202 Handy Steno	128MB	OK
Sandisk	SDCZ2-128 Cruzer mini	128MB	OK
Databar	-	512MB	OK
Kingston	Data Traveler 100 Capless	1GB	OK
Kingston	Data Traveler II+ MIGO	2GB	OK
Corsair	Flash Voyager	1GB	OK
Corsair	Flash Voyager	2GB	OK
Verbatim	Store 'n' Go Standard Red	1GB	OK
Dane-elec	zMate Pen	1GB	OK
Freecom	Databar 2007	1GB	OK

Other brands/types might also work, but you may experience problems when using the “USB Copy” function.

Bosch strongly recommends not to use the following USB memory devices:

Brand	Type	Size	Test
Sandisk	Cruzer Micro	1GB	Failed
Sandisk	Cruzer Micro	2GB	Failed
Lexar	JDX256 Jumpdrive Expression	256MB	Failed
PQI	D33311	128MB	Failed
Stormblue	USD-3531 MicroX	128MB	Failed
Trek	T2MG3M128 Thumbdrive2Smart	128MB	Failed
LG	X-tick	-	Failed


We strongly recommend customers using a DVR4C with firmware version to upgrade to version 1.2.6 or higher when using the “USB Copy” function. New firmware and upgrade instructions are available on the Bosch Security Systems website.

From  
Product  
Management

Eindhoven  
26.11.2008  
No. 26110801

## DVR4C List of recommended USB memory devices

In case you experience any problems, make sure that your USB memory stick is formatted as FAT (= FAT16) using a Windows PC, that it is checked for errors and bad sectors, and that the USB stick is safely removed from the PC.



In case you have any questions, please contact your local Bosch Security Systems representative.